

查出 Default Gateway

```
ev C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [版本 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\rdtest>ipconfig

Windows IP Configuration

Ethernet adapter 區域連線:

    Connection-specific DNS Suffix  . :
    IP Address . . . . . : 192.168.1.2
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.1.1

C:\Documents and Settings\rdtest>
```

查得 IP 位址為 192.168.1.1 後，開啓 admin 輸入 0000



TCP/IP 設定->外部網路設定

設定基地台連接到外部網際網路的參數，可由下拉式選單來選擇變更固定IP,DHCP, PPPoE, PPTP等存取模式。

外部網路存取模式:	固定IP
IP位址:	60.251.140.6
子網路遮罩:	255.255.255.0
預設閘道:	60.251.140.254
網域名稱系統1:	168.95.1.1
網域名稱系統2:	
網域名稱系統3:	
複製 MAC 位址:	000000000000
UPnP	<input checked="" type="checkbox"/> 啟用
外網回覆Ping	<input type="checkbox"/> 啟用

啓用 UPnP 功能確認

- 無線網路
- TCP/IP 設定
 - 內部網路設定
 - 外部網路設定
- 防火牆
- 系統管理
- 登出

外部網路存取模式:	固定IP
IP位址:	60.251.140.6
子網路遮罩:	255.255.255.0
預設閘道:	60.251.140.254
網域名稱系統1:	168.95.1.1
網域名稱系統2:	
網域名稱系統3:	
複製 MAC 位址:	000000000000
UPnP	<input checked="" type="checkbox"/> 啟用
外網回覆Ping	<input type="checkbox"/> 啟用
	<input checked="" type="checkbox"/> IPsec 啟用
穿越VPN	<input checked="" type="checkbox"/> PPTP 啟用
	<input checked="" type="checkbox"/> L2TP 啟用

確定

重設

DMZ 設定 -> 防火牆 -> 非管制區 -> 啟用 -> 輸入 netTV IP 位址 -> 確定

The screenshot shows the router's web interface for the BLW-54CW3 model. The left sidebar contains a navigation tree with the following items: 設定精靈, 操作模式, 無線網路, TCP/IP 設定, 內部網路設定, 外部網路設定, 防火牆 (highlighted), 連接埠過濾, IP過濾, MAC過濾, 連接埠傳遞, URL 過濾, 非管制區 (highlighted), 系統管理, and 登出. The main content area is titled "非管制區(DMZ)" and includes a descriptive paragraph: "非管制區提供網際網路服務並授權存取私人區域網路。非管制區主機包含可存取網際網路流量裝置，如 Web(HTTP)伺服器, FTP伺服器, SMTP(e-mail)伺服器以及網域名稱系統伺服器。". Below this, the "非管制區:" section has a checked checkbox for "啟用". The "非管制區主機IP位址:" field contains the IP address "192.168.1.2". At the bottom of the settings area are two buttons: "確定" and "重設".

設定完成後將 IP 分享器重新啓動並移除 netTV BOX 電源
待 IP 分享器啓動完成在接上 netTV BOX 的電源