



查出 Default Gateway



查得 IP 位址為 192.168.1.1 後，開啓 guest 輸入



按 MISC 進入找到 UPnP



The screenshot shows the web interface for a ZSR1134 router. On the left is a navigation menu with buttons for Status, WAN Setup, LAN Setup, Wireless, Routing, NAT, Firewall, DDNS, and MISC. The MISC button is highlighted with a red box. The main content area is titled 'MISC' and contains several sections: 'Remote Mgmt' with a 'Management Port' field set to 8080; 'UPnP Setup' which is highlighted with a red box and contains a checked 'Enable UPnP Server' checkbox; 'System Time Setup' showing the current time as Mar 20 2007 12:02:14 and a GMT dropdown menu; 'WAN Link Status & Setup' with a 'WAN Link Status' of Disconnect and a 'WAN Link Setup' dropdown set to Auto; and 'Restore Default / Restart System' with buttons for 'Restore Default' and 'Restart System'.

設定完成後將 IP 分享器重新啓動並移除 netTV BOX 電源

待 IP 分享器啓動完成在接上 netTV BOX 的電源